

Projects (/circuits/projects/)

Contests (/contest/)



## RF 433 MHZ (Raspberry Pi)

By piddlerintheroot (/member/piddlerintheroot/) in Circuits (/circuits/) > Raspberry Pi (/circuits/raspberry-pi/projects/)

51,142


34

2

(cc) BY

Download

nload Favorite





Basic tutorial of how to setup a generic 433 MHZ transmitter/reciever with the Raspberry Pi.







Step 1: Parts



PARTS:

RPI 3 - <a href="https://amzn.to/2VA9pQY">https://amzn.to/2VA9pQY</a>)

4 Amp Power Adapter - https://amzn.to/2CTptWu (https://amzn.to/2CTptWu)

16GB micro SD - https://amzn.to/2SFMwd3 (https://amzn.to/2SFMwd3)

(https://amzn.to/2SFMwd3)120 pcs jumper cable: https://ebay.to/2VAb9cY (https://ebay.to/2VAb9cY)


433 MHZ TX/RX kit: <a href="https://amzn.to/2M9saGC">https://amzn.to/2M9saGC</a>(<a href="https://amzn.to/2M9saGC">https://amzn.to/2M9saGC</a>)

RF Outlet Set: <a href="https://amzn.to/2M91DJu">https://amzn.to/2M91DJu</a>)

(https://goo.gl/PL4ryu)



Step 2: Setup



rpi-rf: <a href="https://pypi.python.org/pypi/rpi-rf">https://pypi.python.org/pypi/rpi-rf</a>)

SSH into Raspberry Pi

- 1. "sudo apt-get install python3-pip"
- 2. "sudo pip3 install rpi-rf"



Step 3: Code

```
recieve.py
   import argparse
   import signal
   import sys
   import time
   import logging
   from rpi_rf import RFDevice
   rfdevice = None
   # pylint: disable=unused-argument
def exithandler(signal, frame):
    rfdevice.cleanup()
       sys.exit(0)
18 logging.basicConfig(level=logging.INFO, datefmt='%Y-%m-%d %H:%M:%S'
                        format='%(asctime)-15s - [%(levelname)s] %(module)s: %(message)s', )
23 help="(
24 args = parser.parse_args()
26 signal.signal(signal.SIGINT, exithandler)
27 rfdevice = RFDevice(args.gpio)
28 rfdevice.enable_rx()
29 timestamp = None
30 logging.info("Listening for codes on GPIO " + str(args.gpio))
31 while True:
       if rfdevice.rx_code_timestamp != timestamp:
            timestamp = rfdevice.
            logging.info(str(rfdevice.rx_code) +
                         " [pulselength " + str(rfdevice.rx_pulselength) +
", protocol " + str(rfdevice.rx_proto) + "]")
        time.sleep(0.01)
   rfdevice.
```

## \*Note use python3

- 1. Run recieve.py and note code, pulselength, protocol
- 2. Run send.py with code, pulselength, and protocol arguments



Step 4: Additional Info

